

This Vehicle is equipped with

- An industry approved low loader flat deck body with hydraulic lifting ramps.
- An industry standard air coupling and electrical plug connection.
- Certified king pin towing connection. Refer to the vehicle load certificate for maximum towed mass (MTM)
- Load restraint points. Refer to the body or chassis certification plate for manufacturer load anchorage points and ratings.
- Electronic braking system (EBS). When equipped with EBS this must always be connected to the towing vehicle and powered up, a safety requirement by law.

Safety Advice Relating to this Vehicle

- Be aware of your operational working environment and look for hazards. Plan first, identify and asses all risks, eliminate or minimise the risk, continually monitor and review for improvement.
- Always enter and exit the vehicle using multiple points of contact, use all available steps and grab handles.
- Always ensure the trailer and truck tow couplings are 100% compatible, and securely locked in place.
 Be cautious and take your time when working with moving items that can cause harm: E.g.: connecting units together, auxiliary ramp engine, load
- restraint devices, tool box doors and latches, loading ramps, heavy machinery.
- Under no circumstances should you or others working around you ever place your body in a position underneath the rear low loader ramps when in operation.
- When loading and unloading the manufacturer recommends the vehicle always be positioned on level ground, in a straight line, and coupled to a towing vehicle to obtain maximum stability.
- Always remain 5 meters clear of the rear low loader ramps when in operation.
- Check all operational items are secure, and all doors are closed before moving the vehicle.
- Check your auxiliary engine is switched off and the ramp safety chains are secure before moving the vehicle.

Legal Details

- Class 5 driver's licence required at minimum to operate this vehicle.
- The maximum open road speed limit is 90 km per hour, the operator of this vehicle must comply under The Official NZ Road Code for Heavy Vehicle Drivers.
- Refer to the NZ Transport Agency Load Certificate displayed on the front body or side chassis rail of the vehicle for the following information: Vehicle model, maximum permissible loadings in kilograms, vehicle tare weight, gross vehicle mass (GVM), maximum towed mass (MTM), axle set ratings, axle spacings, wheelbase, heavy vehicle brake code (HVBC), static roll threshold rating (SRT)
- Axle and vehicle loads must not exceed manufacturer's ratings, tyre capabilities, and all limits specified in the applicable Land Transport Vehicle Dimension and Mass (VDAM) acts, rules and regulations. To view all legislative information regarding these rules, contact the NZ Transport Agency: <u>www.nzta.govt.nz</u> or call <u>0800 108 809</u> or contact <u>facebook.com/transportagency</u>

Important Information

- If you are collecting the vehicle on behalf of another person or business and handing this over to another operator, please ensure you provide this capability sheet to the next operator or transport manager in control of the vehicle to access this information.
- TR Group recommend a daily visual pre-trip inspection be completed on the vehicle by the operator before going into service. If you find any faults, or have any questions or concerns around the safe operation of this vehicle, or are unsure about any of the features or attachments on this vehicle please discuss these with the TR Group rental team before attempting to operate the vehicle.
- This vehicle is fully maintained by TR Group and operates under a set service schedule. Should you have any questions regarding the servicing on this vehicle please contact our maintenance team before attempting to operate the vehicle.
- This capability sheet covers most models available for hire, although some may differ slightly, contact the TR Group rental team if you any questions relating to the operation of this vehicle. Call first, operate second.

TR Group Contact Details - Available 24 hours 7 days per week



Maintenance Team Free phone 0800 80 80 69



Rental Team Free phone 0800 50 40 50



Master Drive Training Team Free phone **0800 637 000** (Transport Industry training available through 12 branches nationwide)

www.trgroup.co.nz

www.masterdrive.co.nz